Approved For Release 2002/06/24 : CIA-RDP75B00285R000400130002-2

OSA	-1315-67
	1

21 March 1967

25X1A	To:					
	Subj	ect:	AIRCRAFT 130 OXYGEN SYSTEM CHECK STATUS FOLLOWING INCIDENT			
	Dea	r Bruce,				
	1.	In the letter to you on this subject, dated March 20th, I noticed that we didn't send you the series of aircraft checks that were accomplished after this incident.				
	2.	2. The following action was taken. However, nothing was found, to indicate a problem with the aircraft's system.				
		A.	Checked flow pressure with disconnect flow tester.			
		В.	Accomplished moisture check.			
		C.	Inspected LOX plumbing between converters and oxygen control panel.			
		D.	With Foxboro moisture monitor, the pressure and moisture was checked at each quantity change of one liter until the system was depleted. (See attached sheet for data).			
		E.	Checked low pressure switches and annunciator lights.			
		F.	Checked low quantity, both annunciator and			
		G.	Replaced control panel, seat disconnect, and hose between control panel plumbing and seat disconnect.			
		н.	Verified that pressure switches were installed in the system per print.			
		I.	Purged, serviced, leak checked, pre-flighted and signed off 781 squawk.			
		J.	Pressure suit also checked and all components changed.			
		K.	Oxygen gages checked within specification.			

Approved For Release 2002/06/24 : CIA-RDP75B00285 000000130002-2

OXYGEN SYSTEM CHECKS

Standby Readings on control panel at start:

No. 1 system 110 p.s.i.

No. 2 system 110 p.s.i.

25X1A

Moisture Monitor Check (GH. No. 316, S/N 25, Mfg. Foxboro)

No. 1 System		No. 2 System				
Liters	Press.	Moisture	Liters	Press.		
7 6 5 4 3 2 1 .5 .4	85 to 80 85 to 80 85 to 80 85 to 80 85 to 80 85 to 80 85 to 70 40 30	-68° or bet		Press. 100* 100 90 90 90 85 80 50	Moisture -68°	
.4	20 10 0					

^{*} Checked 100 p.s.i. reading with disconnect flow tester. Verified reading was good.

Systems would go back up to 110 as soon as flow shut off.

meb